



FM3-5950 Fixing Film Unit Installation

For proper installation of the Fixing Separation Guide, please refer to the illustration below. After installing the Fixing Separation Guide, assure that it is seated properly between the 3 ribs. (If it is installed properly it will be stable, if not it will be loose. Also, if the guide is not installed properly, the spring will be expanded awkwardly.)

Please use the included mylar sheet to place on top of the film unit after installing the film unit, to be used before placing the shutter unit in to position. This will protect the film from being damaged by the shutter unit during installation.


For optimal performance the pressure roller (FC0-5061-000) should also be replaced. This part is available from FIT and ships with new bearings.



****Fusion Image Technology modification to prevent E003 Error Codes****

The White Cap Locks should remain on the Film Unit at all times. They are installed on both end caps of this fixing film unit to assure proper connection.

Please do not attempt to remove the Cap Locks or connectors for any reason. This can cause permanent damage to the Film Unit and will void the warranty.



Fusion Image Technology 

Please call 816-979-1010 for technical support if you encounter any problems during installation.